

Configurations explained


The numbers next to each configuration (eg. 4-3-1) indicate opening options. The first number indicates how many doors (sashes) open per door set.

The second number indicates the number of doors opening to the left, the third, how many doors open to the right.

 $\label{thm:continuous} \mbox{Traffic Doors indicate the master door providing both internal and external access.}$

Shootbolts allow the sliding door sashes to be locked in to place from the inside only. Door configurations with shootbolt handles only provide no external access.

Korniche Bi-Folding Door Configurations



Configurations explained

The numbers next to each configuration (eg. 4-3-1) indicate opening options.


The first number indicates how many doors (sashes) open per door set.

The second number indicates the number of doors opening to the left, the third, how many doors open to the right.

 $\label{thm:constraints} \mbox{Traffic Doors indicate the master door providing both internal and external access.}$

Shootbolts allow the sliding door sashes to be locked in to place from the inside only. Door configurations with shootbolt handles only provide no external access.

Korniche Bi-Folding Door Configurations



Configurations explained

The numbers next to each configuration (eg. 4-3-1) indicate opening options.

The first number indicates how many doors (sashes) open per door set.

The second number indicates the number of doors opening to the left, the third, how many doors open to the right.

 $\label{thm:constraints} \mbox{Traffic Doors indicate the master door providing both internal and external access.}$

Shootbolts allow the sliding door sashes to be locked in to place from the inside only. Door configurations with shootbolt handles only provide no external access.